



**2448 Carroll Lane, Escondido, California 92027**  
**Technical Support and Sales 619-609-3432**  
**Manufacturing and Shipping Office 619-990-6696**  
**Skype and Email Support 7 Days a week at:**  
**Skype: [CruiseROWater](#)**  
**Phone and Text: 619-609-3432**  
**Fax: 760-741-9900**  
**Email: [info@TechnauticsInc.com](mailto:info@TechnauticsInc.com)**  
**Website: [www.TechonauticsInc.com](http://www.TechonauticsInc.com)**

---

**INSTALLATION & MAINTENANCE  
MANUAL FOR THE**

**CoolBlue Marine  
Refrigeration System**

***Keeping Beer Cold and Ice Cream  
Hard for Cruisers since 1968!***

**Rev 2021**

# Table of Contents

## Contents

Introduction .....	5
Theory of Operation .....	6
Theory of Operation .....	7
Typical Installation Instructions .....	8
Cool Blue Refrigeration System Specifications .....	9
Installation and General Instructions .....	10
Fin/Tube Holding Plate Internal View.....	11
Lefthand Right Hand Holding Plate Options .....	12
Lefthand Right Hand Holding Plate Options .....	13
Installation of the Fin/Tube Holding Plate.....	14
Installation of Thermostat .....	15
Thermostat Photos .....	16
Installation of Compressor/Condensing Unit.....	17
Condenser/Compressor Photos .....	18
How to Connect Aeroquip Refrigeration Couplings .....	21
Installation of High and Low Pressure Lines to the Holding Plate.....	22
Holding Plate Photos .....	23
Connecting the Refrigerant Lines to the Condensing Assembly.....	24
Wiring Instructions .....	25
Selecting the Correct Wire Size .....	25
12vdc or 24vdc Wiring Options .....	26
General Wiring Overview.....	26

System Wiring Schematic Low Speed .....	27
System Wiring Schematic 1/3 Speed .....	28
System Wiring Schematic 2/3 Speed .....	29
System Wiring Schematic Full Speed .....	30
Electronic Control Module Connections .....	31
Wiring Diagram .....	32
External Fan .....	32
Operating voltage .....	33
Temperature Switch .....	33
Battery protection system .....	34
Protections and alarms .....	34
Fault Errors and Troubleshooting .....	35
1 Flash – Low Voltage Start Error .....	35
2 Flashes – Condensing Fan Over-Current .....	35
3 Flashes – Compressor Starting Failure .....	35
Over-Amp Condition .....	35
Voltage Spikes/Drops .....	35
4 Flashes – Compressor Overload .....	36
5 Flashes – Electronic Controller Overheat .....	36
6 Flashes – Electronic Controller Fault .....	36
Initial Start-up and Starting System with a Warm Plate .....	37
Compressor Speed Set-point and Explanation .....	38
Troubleshooting Section .....	40
Troubleshooting the Thermostat .....	40
Excessive Frost on Holding Plate (Defrosting and Hatch Seal Leaks) .....	40

Bubbles in the Sight Glass .....	40
Recharge Instructions .....	41
Helpful Recharge Charge Hint: .....	43
TECHNAUTICS COOLBLUE LIMITED WARRANTY .....	44
Spare and Replacement Parts and Pricing .....	45

## Table of Figures

Figure 1: Theory of Operation .....	7
Figure 2: Freezer/Refrigerator Box with Divider .....	8
Figure 3: Down-Right Holding Plate Internal View .....	11
Figure 4: Cold Plate Mounting Blocks .....	15
Figure 5: Thermostat Sensing Line Location.....	16
Figure 6: Thermostat Mounted Inside Housing Bracket.....	17
Figure 7: Front View of Compressor Assembly .....	18
Figure 8: Left Side of Compressor Assembly .....	19
Figure 9: Right side of Compressor Assembly .....	19
Figure 10: Top View of Condenser Assembly .....	20
Figure 11: Tightening Aeroquip Fittings with 3/4" and 5/8" Wrenches .....	21
Figure 12: Holding Plate in Custom Foam Lined Box .....	23
Figure 13: Cold Plate Refrigerant Connection Lines .....	23
Figure 14: High and Low Side Refrigerant Lines .....	24
Figure 15: Electrical System Wiring Schematic Low Speed .....	27
Figure 16: Electrical System Wiring Schematic 1/3 Speed.....	28
Figure 17: Electrical System Wiring Schematic 2/3 Speed.....	29
Figure 18: Electrical System Wiring Schematic Full Speed.....	30
Figure 19: Terminal Lever Lifted      Figure 20: Wire Inserted in Terminal      Figure 21: Terminal Lever Closed.....	31
Figure 22: Compressor Electronic Control Module Wiring .....	32
Figure 23: Initial Start-up Speed Setting for Warm Plate.....	37
Figure 24: Compressor Recharge Port for Adding Freon .....	41

## Introduction

For over 50 years Technautics has been manufacturing the most energy efficient marine refrigeration systems available on the market, known as “CoolBlue Refrigeration Systems” or **CoolBlue** for short. CoolBlues are not mass produced in China, but rather built with pride and attention to detail at our production facility in Escondido, California. Every CoolBlue system undergoes multiple quality control and assurance procedures during the fabrication process culminating in a full system hook-up and bench test run to assure system performance prior to shipping. There’s a reason we can offer a full 5-year warranty while competing systems all have much shorter warranty periods: Quality Design, Quality Build, and Quality Assurance.

The CoolBlue comes entirely pre-charged with the required 24oz of R-134a refrigerant and with the use of Aeroquip self-sealing refrigeration connectors; installation is a simple plug-n-play process. The CoolBlue system is designed so that no refrigeration technical experience is necessary for the installation, start-up, on-going maintenance, or even trouble shooting.

This manual covers the installation of the CoolBlue and we can’t stress this enough, even if we do put it in Bold Red.

**Please read all instructions in this manual before beginning the installation process and if you have any questions at all, please contact us 7 days a week for technical support. An easy phone call, email, text, or even Skype can save you time and headache and we are here to help you!**

A CoolBlue refrigeration system is comprised of four major components. We will list these below and then follow-up for each component in greater detail later in the manual.

### **CoolBlue Supplied components:**

1. Compressor/Condensing Unit
2. Fin/Tube Holding Plate with Expansion Valve and Mounting Brackets
3. Thermostat with Mounting Bracket
4. High and Low-Pressure Copper Tube Set:
  - 1/4” High-Pressure Liquid Refrigerant Supply Line (Red Caps)
  - 3/8” Low-Pressure Gas Refrigerant Return Line (Blue Caps)

## Theory of Operation

You certainly don't need to fully understand the detailed thermodynamics that make the CoolBlue system work so efficiently, but a basic overview of the system that will keep your beer cold and ice cream hard is always worth going over. Perhaps the most basic point about refrigeration which is commonly misunderstood is that a refrigeration system does not put cold inside your freezer or refrigerator box. A refrigeration system removes heat, which then leaves cold. Cold is simply the absence of heat, in much the same way that darkness is the absence of light. To darken a room, you remove the light from the room but you can't add darkness. Understanding that the condition of cold is the absence of heat helps illustrate the importance of good insulation and hatch seals, because heat energy wants to flow towards cold. If the insulation and hatch seals can't efficiently keep heat from re-entering the box, then even the best refrigeration system won't be able to keep the beer cold.

Figure 1, represents the CoolBlue refrigeration system. Starting with the pressurized liquid refrigerant ahead of the fin/tube holding plate evaporator at Point A, the introduction of liquid refrigerant is regulated by a thermally adjusting expansion valve (TXV) that is controlled by temperature and pressure. The pressurized refrigerant is reduced in pressure across the expansion valve from high pressure liquid (Point A) to low pressure liquid before entering the fin/tube evaporator holding plate (Point B). The expansion valve acts as a boundary between the high and low-pressure sides of the system and uses the holding plate exit refrigerant gas temperature to throttle in more or less liquid refrigerant. This is based upon feedback from the temperature of the expansion valve bulb attached to the outlet tube of the plate.

Once inside the holding plate, the low-pressure refrigerant begins to boil off, absorbs heat from the eutectic solution, and begins to evaporate. The refrigerant liquid and vapor passing through the fin/tube holding plate evaporator coil continues to absorb heat until it is completely evaporated and turns into gas (Point C). The now heated gas is drawn through the suction line to the compressor suction (Point D). The increased pressure produced in the compressor causes the gas to compress and heat and flow into the condenser (Point E). In the condenser, heat is removed causing the refrigerant gas to condense back to a liquid refrigerant form. The liquid refrigerant is collected and stored in the filter/drier (Point F) and is available to begin the cycle again. The thermostat (G) is monitoring the temperature of the holding plate and turning the compressor on/off to ensure that the eutectic solution is never allowed to defrost and undergo a phase change from solid back to liquid.

## Theory of Operation





Figure 1: Theory of Operation

## Typical Installation Instructions

The CoolBlue refrigeration system can be utilized for a dedicated refrigerator box, a dedicated freezer box, or a combination freezer and spill-over refrigerator box, with the addition of a thermal divider.


The spill-over combination box is a very common installation approach using the CoolBlue for boats with a single existing insulated box. Typical installations position the divider to form a  $\frac{1}{4}$  or  $\frac{1}{3}$  freezer compartment with a larger  $\frac{3}{4}$  or  $\frac{2}{3}$  refrigerator compartment. As shown below, the holding plate is mounted in the freezer section and the addition of a thermal divider regulates the amount of cold air that spills-over into the refrigerator. The thermal divider should be 1" of polyurethane foam covered with a water proof material, such as fiberglass, ABS plastic, or Formica. Air passages cut through in the divider can be lined with PVC or a similar tubing material, trimmed to length, and caulked. This will protect the insulating material from moisture penetration. The foam, water proof covering, and materials needed for construction of the thermal divider can all be purchased at your local Home Depot.

In most spill-over installations, the natural convection air movements will be sufficient to maintain adequate cooling in the refrigerator. The CoolBlue thermostat is cycling the compressor unit to keep the holding plate and freezer at the temperature set-point and the flapper valve in the thermal divider is used to maintain the refrigerator temperatures. In some cases, a thermostat mounted in the refrigeration box can be used to pull cold air from the freezer into the refrigerator box if the natural convection current is not sufficient to maintain adequate refrigerator box temperatures.



Single Box with Thermal Divider

### Divider Hole Layout



- A 1" gap should be left between the top of the box & the top of the divider or two (2) one- inch holes can be placed at the top (as pictured)
- Place a 2.5" hole on center up 1.5" from the bottom of the box. Install a piece of plastic over the hole that can be moved to control the air flow

Figure 2: Freezer/Refrigerator Box with Divider



## Cool Blue Refrigeration System Specifications

CoolBlue Compressor/Condensing Unit Dimensions and weight:	10" W x 12.25" D x 8.5" H, 20lbs
Standard Fin/Tube Holding Plate Size Options: Right and Left Hand Down Left and Right (Custom in all sizes)	24" Height x 13" Width x 2.5" Thick 26lbs 22.5" Height x 14" Width x 2.5" Thick 26lbs Measurements Without Holding Blocks
Length of copper line set:	Available from 2ft to 50ft. 12ft is Standard
Fin/Tube Holding Plate Evaporator Metering:	Thermally Adjusting Expansion Valve
Power Usage When Plate is Frozen:	Variable 3.5 to 8 Amps at 12v depending on Compressor speed and box heat load.
Voltage Acceptance:	Autosensing for 12v or 24v
Variable Compressor Speed RPMs:	2000, 2500, 3000, and 3500 RPM
Type and Volume of Refrigerant:	24oz of R-134a (Do Not use additives, dyes or any type of Leak stoppers)
Steady State High and Low Pressure Ranges Taken ONLY with a frozen plate:	Low Side 0-5 PSI High Side 90-130PSI
Ambient Operational Temperature Range:	Minimum of 14°F (-10°C) Maximum of 120°F (55°C)
Condenser Temperature Range of Operation: (Air Only Water Not Needed Even in the Tropics)	Stable Load Conditions 140°F (60°C) Peak Load Conditions 158° F (70°C)
Compressor Storage Temperature:	Down to -31°F (-35°C)

## Installation and General Instructions

The CoolBlue refrigeration system has been designed and the manual written so that the average cruiser can not only install the system himself / herself, but trouble shoot and make most needed repairs without having to hire an expensive (and sometimes questionably trained) refrigeration technician.

As seems to be the case with the majority of equipment installation projects on a boat, the most challenging part of the install is the layout. Where do you mount the individual pieces and what is the best way to connect them together without having to run through every locker on the boat? As live aboard cruisers ourselves, we know how these projects go. Taking some time to think through your installation can often save lots of headache and an installation project retreat and re-do. Mounting and operational considerations for the individual system components are given in greater detail in the following manual sections, and we are available 7 days a week to assist you with the installation.

After mounting the components, the CoolBlue is designed to be Plug-n-Play:

1. Two color coded refrigeration copper lines to connect on the Holding Plate.
2. Two color coded refrigeration copper lines to connect on the Compressor/condensing unit
3. Four electrical connections to make on the compressor/condensing unit electronic controller module and 2 on the Thermostat.

Once these connections are made, the CoolBlue is ready to be turned on.

A common question we receive is, "What can I do wrong during the installation that breaks something" and our standard answers are pretty short and easy, so once you get these out of the way the rest of the installation project is pretty easy.

1. Pay attention when hooking up the positive and negative DC power to the electronic control module. If you reverse the polarity you can fry the controller.
2. Work slowly with the copper tube sets to not kink them while running them through the boat and into the box. If you kink one, it will need to be replaced.
3. When connecting the male and female Aeroquip refrigeration couplings, be sure to use a backing wrench as shown in the instructions. If you don't, you risk damaging the fittings or transferring the force past the fitting and breaking the coupling/tubing weld.
4. Work slowly with the thermostat capillary sensing bulb, this is a hollow tube filled with refrigerant gas. If it gets kinked, it will need to be replaced.
5. Last, but certainly not least, the electronic control module is VERY sensitive to voltage drop and spike issues. Skimping on the correct wire size (#10 GA

Minimum) or making messy multiple wire connections on marginal breakers, as well as using non-tinned wire isn't worth the heartache they can cause.

Avoid these 5 installation mistakes and please contact us with any questions!

## Fin/Tube Holding Plate Internal View

Our Company is the only manufacturer, to our knowledge, that uses a tube and fin condenser assembly internal to the cold plate. All other manufacturers use only bent tubing inside their cold plates. By using the tube and fin design there is a greater efficiency in removing the heat from the freezer/refrigerator box as the heat load does not have to penetrate the entire ice cache eutectic solution. Surrounding the tub and fin coils is the eutectic solution which give you the hold over effect. This allows the compressor to cycle less frequently.












Figure 3: Down-Right Holding Plate Internal View

## Lefthand and Right Hand Holding Plate Options



## Down Left and Down Right Holding Plate Options




## Installation of the Fin/Tube Holding Plate


**Caution: Do not drill into the flange of the stainless-steel fin/tube holding plate.**

The fin/tube holding plate is filled with a eutectic solution that freezes at a specific temperature controlled by the thermostat. The varying holding plate configurations (Right Hand, Left Hand, Down Right, and Down Left) are offered to make the copper tube set connections and run from the holding plate through a hole in the box to the compressor/condensing unit as easy and clean as possible. Consider the following points and take the following steps for mounting the holding plate inside your box.

1. Determine the plate position in box to allow for air circulation around the holding plate. The holding plate may be mounted vertically or horizontally, there is no top or bottom to the plate.
2. The plate needs to be mounted as high in the box as possible to help set-up a natural convection air current of cold air sinking and warm air rising.
3. Position the plate so that it fits into the box with clearance for the lid, insulation, etc.
4. When selecting your plate mounting location, plan on where you will be able to drill a hole in the upper-most section inside the box, taking into account the path of the copper lines connecting the holding plate to the compressor/condensing unit.
5. The CoolBlue system is supplied with three (3) holding plate mounting brackets for the sides and bottom of the plate.
6. First install the bottom mounting channel with self-tapping screws to support the plate while the side mounting channels are installed.



Mounting Channel



Mounting Channel Cold Plate

## Installation of Thermostat

**Warning: Do not kink small thermostat sensing capillary tubing.**

The thermostat can be mounted in a convenient location inside the cooling box to allow easy temperature adjustment and close enough to the holding plate so that the capillary sensing tube can be inserted into the copper tube soldered to the side of the holding plate. The thermostat measures the temperature of the holding plate (Not the Box) to keep the eutectic solution frozen for an efficiently running system. Therefore, the tip of the thermostat sensing bulb needs to be inserted  $\frac{3}{4}$  of the way into to copper tube attached to the holding plate.

Different thermostat temperature ranges are used for a freezer or refrigerator holding plate, so if you are replacing a thermostat be sure that your thermostat temperature range matches the eutectic solution in your holding plate. This is an important detail because using a thermostat temperature range that is not matched to the concentration of the holding plate eutectic solution can cause your CoolBlue system to lose efficiency.

The thermostat will control the compressor by sending a signal through two small gage wires to the electronic control unit on the CoolBlue condensing/compressor unit. In selecting a thermostat mounting location, plan ahead for the wire run along with the capillary sensing bulb. If you would like to monitor and display the actual box temperature, we can provide a 12v digital temperature display. Consider the following points and take the following steps for mounting the holding plate inside your box.

1. Using two-sided tape or screws, mount the thermostat on a convenient surface inside the cooling box. You don't want the frost that can build up on the plate to "grow over" the thermostat, so don't mount the thermostat right up against the holding plate.
2. Insert the capillary sensing tube  $\frac{3}{4}$  of the way into the copper tube soldered to the side of the holding plate.
3. Coil and secure excess thermostat capillary sensing tubing to prevent damage.
4. Use #16 - #20 AWG wire to connect the two thermostat electrical connections to the electronic control module located on the compressor/condensing unit.
5. Since the thermostat acts only as a switch, there is no polarity for the thermostat wire connections and small AWG wire will be fine.
6. The thermostat dial settings range from 1 - 7, with 1 being the warmest and 7 being the coldest. 3-4 is the typical set point. Turning counter clockwise past the #1 position until you feel the indent and "click", will turn the CoolBlue system off.



## Thermostat Photos



Figure 5: Thermostat Sensing Line Location






Figure 6: Thermostat Mounted Inside Housing Bracket

## Installation of Compressor/Condensing Unit

### Two Important notes:

To prevent contamination, do not remove Red and Blue protective caps from Aeroquip coupling fittings until final connection is ready to be made.

The compressor/condensing unit **MUST** be mounted on a level surface and in the upright position.

Mount the compressor at or below the cold plate if at all possible. The oil in the compressor circulates through the system and returns to the compressor. If the compressor is too high above the cold plate you run the possibility of starving the compressor of oil and damaging the unit. Consult with Technautics if you need to mount the compressor higher.

Any convenient location that has sufficient air circulation over the condensing coils. Installations in an engine room are OK if that is your most convenient space. Allow at least 3" of clearance around the condensing coils for free air circulation. If installed in a restrictive compartment like under a bunk or setae, air vents can be installed to allow for additional air circulation. You also have an option to install a 12v cooling fan that will turn on and off with the compressor to assist in venting the compartment where natural air movement isn't adequate. Consider the following points and take the following steps for mounting the compressor/condensing unit.


1. Mount the DC compressor/condensing unit on a level platform and secure it to the platform through the mounting holes in each corner of the condensing unit.
2. The CoolBlue comes standard with a 12ft copper tube set, but longer copper tube sets of up to 50ft can be provided.
3. Do not install the compressor/condensing unit higher than the top of the stainless-steel fin/tube holding plate. Contact Technautics for approval if you need to be higher.
4. You will want to be able to observe the sight glass on the top of the dryer/receiver to check the refrigerant charge level, so keep that in mind for your installation.
5. The compressor can operate continually at a heel angle of 30° but must be mounted on a level secure platform.

6. The compressor/condenser unit is hermetically sealed, but the electronic control module is susceptible to water splash or spray damage, so chose a mounting location well protected from the elements.

## Condenser/Compressor Photos



Figure 7: Front View of Compressor Assembly




**Figure 8: Left Side of Compressor Assembly**



**Figure 9: Right side of Compressor Assembly**

**This Section Left Intentionally Blank**





**Figure 10: Top View of Condenser Assembly**

**This Section Left Intentionally Blank**

## How to Connect Aeroquip Refrigeration Couplings

### Two Important notes:

**To prevent contamination and damaging the O-rings in the ends of the Aeroquip refrigeration coupling fittings, do not remove the protective color-coded caps until you are ready to make the final connections.**

**Always use a backing wrench when tightening the Aeroquip refrigeration couplings.**

1. The Female refrigeration coupling has a Nut that will spin to allow the Female and Male fittings to be joined together. (Matching the color-coded caps)
2. Start the connection by hand, turning ONLY the Female nut. A  $\frac{3}{4}$ " wrench needs to be placed on the Female nut while a  $\frac{5}{8}$ " backing wrench is placed on the Male refrigeration coupling to firmly hold it in place.
3. The connection is tightened to 10ft-lbs.
4. How much is 10ft-lbs? Just snug together the fittings by turning ONLY the Female nut on the left in the photo below while holding the Male fitting in place which is on the right side. You don't want to over tighten the fittings and warp their shape or tweak the sealing O-ring. Make a firm snug connection with just one finger on each wrench is fine. You don't need more than two fingers of pressure on the wrenches to make a good seal; keep the breaker bar in the tool box!
5. It is common to hear the refrigerant start to flow as the Male and Female fittings are joined together and a small amount of refrigerant gas escaping during this process isn't something to panic about.
6. The Aeroquip fittings are multiple use self-sealing type fittings and can be disconnected without losing refrigerant.




Figure 11: Tightening Aeroquip Fittings with  $\frac{3}{4}$ " and  $\frac{5}{8}$ " Wrenches

## Installation of High and Low Pressure Lines to the Holding Plate

### Two Important notes:

**To prevent contamination and damaging the O-rings in the ends of the Aeroquip coupling fittings, do not remove the protective color-coded caps until you are ready to make the final connections.**

**Work slowly and gently with the copper lines to avoid kinking them.**

Because you want any extra copper tube length to be coiled at the compressor and not in your refrigeration box, we recommend making the connections on the holding plate first. Then work your way back to the compressor forming the lines and strapping them cleanly along the way. The 1/4" liquid supply copper line does not require insulation for the function of the unit; however, we recommend covering the 3/8" return copper tube with protective insulation commonly used for hot water lines (available at Home Depot) as a way to insulate and protect them from chafe and impact damage. **The insulation on the return line prevents condensing of the gas to liquid which will cause damage to the compressor.**

The two Female Aeroquip refrigeration fittings on the holding plate are identified by color coded caps.

1. The red cap identifies the high-pressure inlet for the refrigerant liquid entering the expansion valve.
2. The blue cap identifies the suction low-pressure holding plate outlet for the refrigerant gas returning to the compressor.


The two copper lines with Male Aeroquip fittings connect the holding plate to the compressor unit and in addition to their size difference; they also have the red and blue color-coded caps which match up to the corresponding Female attachment points.

1. The red cap identifies the 1/4" high-pressure line that will connect to the red cap on the holding plate expansion valve inlet.
2. A blue cap identifies the 3/8" suction-low pressure line that will connect to the blue cap suction low-pressure holding plate fitting.

## Holding Plate Photos



**Figure 12: Holding Plate in Custom Foam Lined Box**



**Figure 13: Cold Plate Refrigerant Connection Lines**



## Connecting the Refrigerant Lines to the Condensing Assembly

### Two Important notes:

**To prevent contamination and damaging the O-rings in the ends of the Aeroquip coupling fittings, do not remove the protective color-coded caps until you are ready to make the final connections.**

**Work slowly and gently with the copper lines to avoid kinking them.**

The two Female Aeroquip fittings on the compressor/condensing unit are identified by color coded caps.

1. The red cap identifies the high-pressure outlet fitting for the refrigerant liquid exiting the filter/dryer.
2. The blue cap identifies the suction low-pressure compressor inlet fitting for the refrigerant gas returning to the compressor.

The two copper lines with male Aeroquip fittings connect the holding plate to the compressor unit and in addition to their size difference; they also have the red and blue color-coded caps which match up to the corresponding female attachment points.

1. The red cap identifies the 1/4" high-pressure line that will connect to the red cap on the outlet of the filter/dryer.
2. The blue cap identifies the 3/8" suction low-pressure line that will connect to the blue cap suction low-pressure port on the compressor inlet.



Figure 14: High and Low Side Refrigerant Lines



## Wiring Instructions

### Three Important notes:

Reversing the Polarity of the positive and negative power connections **WILL DAMAGE** the electronic module. Pay close attention when making the connections and be sure to have the breaker turned off while making the connections.

The CoolBlue should have a dedicated 15A DC breaker not shared with another device to minimize voltage spikes and losses.

You purchased the most energy efficient refrigeration system on the market, so don't jeopardize the system performance by going cheap and skimping out on using the correct wire size! A large portion of our troubleshooting calls are voltage related.

### Selecting the Correct Wire Size

Use the below wiring size table to select the correct sized wire based on the distance of the compressor/condensing unit to your ships DC power distribution source. Remember that an electrical load 10 ft. away is really 20 ft. away for wire size calculations because you have to count both directions of the electrical run. We recommend at minimum at #10 size wire.

**AWG Wire Sizes for 12v System Based on a 3% Voltage Drop**  
(Recommended for Voltage Sensitive Components/Motors)

Total Current on Circuit in Amps	Total Length of wire run in Feet										
	20	30	40	50	60	70	80	90	100	110	120
5	10	10	10	10	10	8	8	8	8	8	6
10	10	10	8	8	6	6	6	5	5	5	4
<b>15</b>	<b>10</b>	<b>8</b>	<b>6</b>	<b>6</b>	<b>6</b>	<b>5</b>	<b>4</b>	<b>4</b>	<b>3</b>	<b>3</b>	<b>2</b>
20	8	6	6	4	4	2	2	2	2	2	1
25	8	6	4	4	2	2	2	1	1	1	0
30	6	4	4	2	2	-	-	-	-	-	-
40	6	4	2	2	1	-	-	-	-	-	-
50	4	2	2	1	1/0	-	-	-	-	-	-

Table 1

## **12vdc or 24vdc Wiring Options**

The CoolBlue is capable of running from a 12vdc or 24vdc power source. The electronic control module will automatically sense the incoming voltage.

## **General Wiring Overview**

Figure 14 through Figure 17 on the next pages represents the generalized wiring diagram for the CoolBlue refrigeration system. During a warm holding plate start-up, the compressor can momentarily use up to 13A depending upon the speed selection, so it is important that a dedicated 15A breaker be installed on the positive (+) DC power supply wire coming from either the ships battery or ships power distribution panel. It is also important that the negative wire (-) is brought back to the battery negative and not a common grounding buss or engine ground.

The electronic control module is sensitive to voltage spikes and drops, so it is strongly recommended that power be supplied to the unit directly from your house battery bank. Your ships battery will act as a sink and dampen out voltage spikes from charging and load sources to protect the unit from fault or damage. It is not recommended to connect your DC power to a shared buss of charge and load sources. It is also not recommended to connect the negative (-) DC power wire to a common grounding bus or ships engine.

## System Wiring Schematic Low Speed




Figure 15: Electrical System Wiring Schematic Low Speed

## System Wiring Schematic 1/3 Speed




Figure 16: Electrical System Wiring Schematic 1/3 Speed

## System Wiring Schematic 2/3 Speed




Figure 17: Electrical System Wiring Schematic 2/3 Speed



## System Wiring Schematic Full Speed




Figure 18: Electrical System Wiring Schematic Full Speed

## Electronic Control Module Connections

**Important Note: Older models of CoolBlue systems may use a different compressor and electronic module. The Positive (+) and Negative (-) DC power supply positions on the older unit's electronic control module are in opposite locations, so be careful if you have an older unit but have downloaded this newer manual!**

The electronic control module connections on the unit are male spade connectors. We have provided two yellow female spade connectors for the DC power supply and two red spade connectors for the thermostat wires. It is very important that the correct DC power supply polarity is connected. To avoid a mistake which can damage the electronic controller, note closely that the top spade connector is for the DC power negative (-) and the second spade connector is for DC power positive (+). There is no polarity for the thermostat, which simply functions as an open/closed switch.

The electrical connections for the 12v condenser cooling fan have been completed for you and these should not be removed or spliced into another device such as an hour meter or relay for a remote fan.

The below pictures depict how to install wires into the terminal boards to change speeds. When selecting the desired speed terminal board, lift the orange lever up as shown in Figure 18. Insert the thermostat wire into the terminal board opening until it stops as depicted in Figure 19. Close the lever down as depicted in Figure 20 to complete the termination of the wire into the terminal board.



Figure 19: Terminal Lever Lifted




Figure 20: Wire Inserted in Terminal




Figure 21: Terminal Lever Closed

## Wiring Diagram

The electronic driver features a terminal board where all connections are made. The terminal lay out is described in Figure 22:




Figure 22: Compressor Electronic Control Module Wiring

### External Fan

As shown in Figure 22. (5), the positive side of the fan is connected to the (F +) end of the controller, and the negative terminal of the controller is connected to the (F-) terminal of the controller. A terminal of the controller (F +) and (F-) can be connected with a 12V DC fan. When the input voltage of the controller exceeds 12V, the output value between the terminals (F +) and (F-) is always kept at 12V.

Regardless of whether the input voltage system is 12V or 24V, the fan must be a 12V DC fan. B, the controller can continue to output 0.5A fan drive capability.



## Operating voltage

DL series are designed to operate in a wide range of DC voltages, supplied either by a battery or by any other kind of filtered DC power supply.

DC VOLTAGE SUPPLY ALLOWED: 9.6V to 31.5V

Operating Voltage Setting Table

External resistance K $\Omega$	12V Stop value V	12V Boot value V	12V High pressure stop value V	24V Stop value V	24V Boot value V	24V High pressure stop value V
0	9.6	10.9	17.0	21.3	22.7	31.5
1.6	9.7	11.0	17.0	21.5	22.9	31.5
2.4	9.9	11.1	17.0	21.8	23.2	31.5
3.6	10.0	11.3	17.0	22.0	23.4	31.5
4.7	10.1	11.4	17.0	22.3	23.7	31.5
6.2	10.2	11.5	17.0	22.5	23.9	31.5
8.2	10.4	11.7	17.0	22.8	24.2	31.5
11	10.5	11.8	17.0	23.0	24.5	31.5
14	10.6	11.9	17.0	23.3	24.7	31.5
18	10.8	12.0	17.0	23.6	25.0	31.5
24	10.9	12.2	17.0	23.8	25.2	31.5
33	11.0	12.3	17.0	24.1	25.5	31.5
47	11.1	12.4	17.0	24.3	25.7	31.5
82	11.3	12.5	17.0	24.6	26.0	31.5
220	9.6	10.9	17.0	21.3	22.7	31.5

Table 2

## Temperature Switch

The temperature switch (7) connected to C and T pins, if not connect any resistance in the middle; compressor running speed will be 2000rpm. Table 3 shows the compressor running speed according to the resistance value connected between pins C and T.

Compressor speed (rpm)	C/T Resistance $\Omega$	C/T Current mA
2000	0	5
2100	51	4.8
2200	100	4.6
2300	150	4.4
2400	200	4.2
2500	277	4
2600	330	3.8
2700	400	3.6

Compressor speed (rpm)	C/T Resistance $\Omega$	C/T Current mA
2800	490	3.4
2900	586	3.2
3000	692	3
3100	816	2.8
3200	963	2.6
3300	1137	2.4
3400	1331	2.2
3500	1523	2

Table 3

## ***Battery protection system***

There is a protection system for the battery that prevents the compressor from operating if the available voltage becomes too low. The electronic driver determines the stop compressor and restarts the compressor by detecting the voltage between the input terminals (+) and (-) to protect the different power supply batteries.

The standard battery protection settings recommended value in Table 3; other voltage can be set by adjusting the controller terminal (C) and (P) connection resistance (9), the specific value of Table 3.

12V Cut-out (V)	12V Cut-in (V)	24V Cut-out (V)	24V Cut-in (V)
10.4	11.7	22.8	24.2

**Table 4. Limits of battery protection parameters**

## ***Protections and alarms***

DL series are electronically protected against a number of possible malfunctions and failures. As shown in Figure 1:

The controller terminal (+) and (D) can be connected between a 10mA LED (6) for the display fault, LED anode connected to the controller (+) side, the cathode connected to the controller (D) end.

When the failure occurs, LED every 3 seconds for the cycle, continuous flash in each cycle, according to different failures flash different times, each flashing for 0.4 seconds, continuous flashing for 3.2 minutes. The number of specific codes and blinks is shown in Table 4.

N° of blinks	Fault type
1	Voltage fault - The input voltage is outside the set range
2	Fan current fault - fan current output current greater than 1A
3	Compressor start fault - compressor motor stall or system pressure too large (> 6kg)
4	Compressor minimum speed fault - The compressor is overloaded or the motor speed is too small.
5	Controller temperature fault - controller housing temperature too high (> 85 ° C)
6	Controller hardware failure - The controller has detected an abnormal parameter

**Table 5. Alarm codification**

## **Fault Errors and Troubleshooting**

### **1 Flash – Low Voltage Start Error**

The electronic controller did not see the DC power supply voltage stay above the minimum during the starting sequence. It will abort the start attempt until proper voltage is detected. To correct the problem, check your DC power connections and turn on a battery charger or ships alternator to increase battery voltage. Just because your ships electrical panel is showing 13v doesn't mean the 13v is getting to the CoolBlue, so check the voltage at the CoolBlue power terminals to verify the voltage actually getting to the CoolBlue. Voltage drop on boats is very common from undersized wires, poorly made or corroded connections and voltage loss due to passing through too many connectors.

### **2 Flashes – Condensing Fan Over-Current**

The electronic controller sees more than a 1 amp draw from the condensing unit fan. The fan typically draws 0.29A but could fault if blocked or if the bearings in the fan are beginning to fail. Can also indicate an auxiliary load has been added to the fan circuit that exceeds the maximum amperage for the channel. The compressor cannot be operated without the cooling fan except for brief trouble shooting tests with the fan removed to determine if the Fault error will clear.

### **3 Flashes – Compressor Starting Failure**

If the compressor running speed is not achieved during the start-up sequence, the fault condition occurs. This fault condition is typically not a compressor problem, but rather, a voltage spike/drop, or an over-Amp situation during the start-up sequence. Two easy trouble shooting techniques can be used to identify the actual cause of the Fault.

#### **Over-Amp Condition**

This Fault Error commonly occurs if starting the CoolBlue system with a warm holding plate with the compressor not set for low speed. To remedy, select a lower speed to start the compressor on. The compressor should be left on low speed or 1/3 speed for the initial start-up until frost starts to appear on the holding plate. Then the speed can be set higher if the desired temperature setpoint cannot be reached.

#### **Voltage Spikes/Drops**

The electronic control module is much more sensitive to voltage issues than you can see with a typical hand held volt meter or a ships voltage display. So just because you see 13.2v on your ships voltage panel, you can't assume that the controller is seeing adequate voltage during the compressor start-up sequence. An easy trouble shooting technique to rule out a wiring or voltage drop problem is to

run a temporary DC power wire directly from the ship's battery positive and negative terminal to the power supply leads on the electronic control module. This will eliminate all of your ships wiring and possible loose connections.

If the electronic controller is still giving the 3-Flash error fault after trying both the compressor speed reduction and wiring directly to the ship's battery, it could be that the electronic controller has failed and needs to be replaced. Unfortunately, there is no way to field test the electronic module except to test it on a known working compressor and power supply system. Electronic control module death is determined by a process of elimination by ruling out the other possibilities.

There is an extremely rare chance that a failed compressor is giving you the 3-Flash fault, but quite honestly, it is so rare for these compressors to fail within their 200,000-hour service life span that we don't start the trouble shooting process with that assumption. We have thousands of these systems sailing the seas with 15yr old compressors. This means that if you have an island refrigeration service tech telling you that your compressor has failed and he hasn't conducted the above tests, call us immediately 7 days a week (or skype) and get his hands off the unit ASAP before he does more harm than good!

#### **4 Flashes – Compressor Overload**

This Fault condition occurs when the compressor speed drops below a minimum speed, indicating an overload condition. Common causes can be due to a system overcharge or excessive heat loads.

#### **5 Flashes – Electronic Controller Overheat**

This Fault condition occurs if the temperature of the electronic control module gets too hot as a way to protect the electronic control module from burn-out. The controller will shut itself down to allow time for the electronic control module to cool down. This is a relatively rare Fault since the CoolBlue has been designed with the 12v condensing cooling fan blowing directly on the heat dissipation fins on the back of the electronic control module.

#### **6 Flashes – Electronic Controller Fault**

This fault occurs when the controller detects an abnormal internal parameter. This cannot be remedied other than replacing the controller.

## Initial Start-up and Starting System with a Warm Plate

Starting the CoolBlue with a warm holding plate should be done with the compressor speed setting at 1/3 speed or low speed. This will minimize the start-up amp draw and will keep the electronic control module from shutting down the unit due to an over-amp fault, and showing the 3-Flash LED error code. Once the holding plate starts to develop frost, the compressor speed can then be left at 1/3 speed or slow speed if the unit will cycle within 12 hours. The slower the speed setting where you can maintain desired temperature the greater the energy savings.

The speed control settings are located on the side of the electronic control module. For low speed, one leg of the thermostat wire is landed on the low speed terminal board. The other leg is landed on the "C" terminal of the control module. Each desired speed setting will require you to move the wire to any of the speed setting terminals required while leaving the other thermostat wire on terminal "C" of the control module. See Figures 14, 15, 16, and 17 for the different speed settings.




Figure 23: Initial Start-up Speed Setting for Warm Plate

To start the CoolBlue, first turn the thermostat dial in the box to the off position, which is the indent passed the No1 setting. Next turn on the 15A DC power supply breaker. DC power should now be supplied to the electronic control module but until it sees a completed circuit from the thermostat it will remain in standby mode. Turn on the thermostat and set it to the normal starting temperature of between 3 and 4 on the dial indicator. You should now hear the 12v condensing unit fan start along with the near silent compressor and within a few minutes you should start to feel the outlet side of the expansion valve on the holding plate starting to get cold. The controller has a speed ramp algorithm setting internal circuitry. No matter what speed you set the controller to it will start up to about 4 to 4.5 amps and hold for one minute before accelerating to the speed setpoint you have selected. This allows the controller a chance to build pressure slowly and not have an over amperage condition. Once the holding plate starts to develop frost, the compressor speed can then be left where it is or moved to a lower number where you can still maintain the desired temperature in your box.

It typically takes from 8-15 hours to initially freeze down the holding plate and bring the box down to equilibrium temperatures before the compressor will begin the normal on/off cycling.

If you are running a spill-over freezer/refrigerator box, once the compressor starts cycling, you can then start adjusting the swing door placed in the thermal divide to dial in your refrigerator temperature.

### ***Compressor Speed Set-point and Explanation***

The CoolBlue compressor controller has 4 manual speed settings set by the position of one of the legs of the thermostat wires located on the side of the electronic control module.

Low - 2000 RPM, 1/3 -2500 RPM, 2/3 -3000 RPM, and Full Speed -3500 RPM

Unlike a critical orifice thin rolled aluminum evaporation plate type refrigeration units that have no hold over capacity that benefit from matching the compressor speed to the heat uptake of the evaporator, holding plate systems are designed for the compressor to pull out more heat than can be absorbed by the holding plate. So on holding plate systems, the intent is to “store cold” in the holding plate eutectic solution to allow for longer compressor off periods and less compressor cycling. In fact, where thin rolled evaporators would cycle on and off up to 177 times in a 24-hour period, a holding plate system would only need the compressor to cycle on and off from 4-8 times depending upon insulation, temperature of day, and temperature setting!

From an efficiency standpoint, you would like to run the compressor at the slowest speed setting that will still allow for about a 50% compressor duty cycle. From experience we have found that the compressor speeds of 2/3 speed or lower works well for most

installations, but larger boxes, boxes with poor insulation, or while cruising in tropical climates a compressor speed of full could be needed for good cycle time intervals and proper box temps.

In terms of power usage relating to speed and run time for a math example, but not necessarily representing real-life numbers, a compressor on full speed will use, let's say, 10A DC while running and for example will cycle on for 1 hour to freeze down the holding plate. If the speed of the compressor is cut to 1/2 speed, then the compressor will use approximately 5A DC but will need to run for 2 hours to freeze down the holding plate. There is a small efficiency advantage of running at the lower speeds, but in general the daily power used in terms of Total Amp hours will be close to the same in the example above:  $5A * 2hrs = 10AH$  or  $10A * 1hr = 10AH$ .

The advantage of the higher compressor speeds is that the system will have a faster response time in pulling down the box temperature when stocking up the freezer/refrigerator with lots of provisions. If you just landed a big Dorado and want to put the filets in the freezer, the higher compressor speed will help freeze the fish faster. The disadvantage is that the instantaneous power Amp draw will be greater at the higher speeds, so life's a balancing act and you can decide for yourself how you would like to operate your system.

This Section Left Intentionally Blank

## Troubleshooting Section

### Troubleshooting the Thermostat

The thermostat acts as an Open/Closed circuit that the electronic control module senses to turn the compressor on and off. If the thermostat fails in the open position the compressor unit will not turn on. If the thermostat fails in the closed position, the compressor will not turn off. If your compressor will not turn on and you have verified you have good voltage at the electronic controller connections you can put in a jumper around the thermostat. If the compressor starts with the thermostat jumped, then you know the thermostat has failed and can be replaced. If on passage with a failed thermostat, you can run the system by leaving the thermostat jumped and manually turning off and on the system several times a day to keep the holding plate frozen.

### Excessive Frost on Holding Plate (Defrosting and Hatch Seal Leaks)

It is common for humidity in the air to condense and form frost on the holding plate surface. Once the frost starts turning to ice and grows to over ¼" thick, the frost/ice starts acting as an insulator making it more difficult for heat to be absorbed from the box into the holding plate. This can significantly affect the overall efficiency of the refrigeration system and your box temperatures. It is recommended that an ice scraper or spatula is used on the holding plate to keep frost/ice down to a minimum. The 316 stainless steel construction of the holding plate makes it safe to scrape the frost/ice regularly from the holding plate.

Rapid frost build-up on the holding plate is a sign of an air leak. Since hot flows to cold, warm moist air is being drawn into the box most likely through poor hatch or door seals. A trouble shooting approach to see if your box seals are doing their job is to use blue painter's tape to seal your box hatch for a few days. If you notice a slowing of the frost formation, then it is time to do some work on your box hatch seals.

### Bubbles in the Sight Glass

The CoolBlue system holds 24Oz of R-134a refrigerant and when the system is low on refrigerant you will see bubbles appearing in the sight glass. Along with the bubbles, you will notice the system running for longer periods of time and not getting as cold, which is a classic sign of a unit low on refrigerant. A few small "bb" type of bubbles are ok, but the presence of larger bubbles or if your sight glass looks like an old fashioned "coffee percolator" then it's time to add some refrigerant to the system. For a detailed description of the recharge process see page 31.



## Recharge Instructions

**Caution: Wear appropriate hand and eye protection when charging the system. The Liquid refrigerant will freeze what it comes in contact with: skin, eyes, and moles!!**

### Important Notes:

**Charging a holding plate system utilizing a thermally adjusting expansion valve and dryer/receiver is NOT like charging a critical charge system utilizing a fixed critical orifice. So put your Refrigeration Gauges away. Charge the system by volume (24Oz is a full charge) or by using the sight glass to determine the proper state of charge.**

**ONLY use pure R-134a refrigerant gas. Do not use refrigerant with leak stopper, performance boosters, or dyes. These additives will foul the system.**

The CoolBlue refrigeration system is designed to be easily rechargeable if it is determined to be low on refrigerant. The following steps can be used to top off the system with the correct 24Oz of R-134a refrigerant by observing the sight glass. Refrigerant isn't like garlic and you can add too much, so before adding refrigerant, make sure your system is indeed undercharged. Bubbles in the sight glass can help and if you have any questions at all, just call or text the Technautics technical support line 7 days a week at 619-609-3432.



Figure 24: Compressor Recharge Port for Adding Freon

1. Locate and identify the following:
  - A. Sight Glass – the 3/8" diameter glass window on top of the receiver/drier by the compressor unit.
  - B. Suction low-pressure Service Valve – the blue painted cap located on the compressor.
2. Adjust the thermostat as needed to make the compressor run.
3. After 10 minutes of operation, observe the sight glass. If bubbles are present, the system needs to be charged.
4. Completely open the valve on the charging hose by turning the valve counter clockwise, which retracts the refrigerant can piercing needle.
5. Tightly connect the charging hose to the refrigerant can.
6. Completely close the valve on the charging hose, which will deploy the can piercing needle so that when you next open the valve refrigerant gas will flow.
7. Remove the blue cap from the suction low pressure service valve and **very loosely** attach the charging hose.
8. Open the refrigerant can valve slightly and purge air from the charging hose for 2 to 5 seconds, then **firmly tighten** the charging hose to suction valve connection.

**Caution: Hold the refrigeration can in the upright position. The compressor is designed to pull in refrigerant gas, not liquid. By turning the can upside down, a slug of liquid refrigerant will flow into the compressor and float out the compressor oil.**
9. Open the refrigerant valve fully to feed refrigerant into the system until the large bubbles are no longer visible in the sight glass. Then close the valve on the charge hose.
10. Continue running the system for 5 more minutes and monitor the sight glass. If large bubbles are still present, repeat step 9.
11. Repeat steps 9 and 10 until no large bubbles are visible.
12. The system is now fully charged. Reset the thermostat to its previous position.
13. Close the refrigerant can valve, disconnect the charging hose, and replace the blue cap.

### **Helpful Recharge Charge Hint:**

Shining a flash light into the sight glass can help illuminate the refrigerant flow stream. If you see nothing at all in the sight glass, it could be that your system is too low on refrigerant to even make bubbles.

There is no visual difference in the sight glass between a correct full charge and an over charged condition, so the key to successfully recharging is taking your time. Because once you overshoot the system charge, you have no visual way to know. Add smaller amounts of refrigerant in 5 to 15 second bursts, letting the system stabilize and then check the sight glass.

If you are having trouble determining your systems state of charge based on the appearance of the sight glass sometimes it is easier to simply start over. Meaning you can remove the refrigerant from the system and simply add two full 12oz refrigerant cans. This way, you know with absolute certainty that your system is charged correctly. The “catch” is that you will need to have a room temperature holding plate to remove the refrigerant from the holding plate and get to what is known in the technical refrigeration world as a “vapor charge” condition. This is useful in system troubleshooting because it rules out a charge problem. Charge problems and voltage drop/spike problems are the most common reasons for a CoolBlue refrigeration system to not function properly.

This Section Left Intentionally Blank

## TECHNAUTICS COOLBLUE LIMITED WARRANTY

BORAMEL INC DBA TECHNAUTICS WARRANTS NEW EQUIPMENT TO BE FREE FROM DEFECTS IN MATERIAL AND WORKMANSHIP FOR FIVE YEARS FROM PURCHASE DATE, EXCLUDING THE ELECTRONIC CONTROLLER. THE ELECTRONIC CONTROLLER HAS A LIMITED ONE YEAR WARRANTY FROM THE DATE OF PURCHASE. THIS WARRANTY DOES NOT COVER ANY MERCHANDISE OR COMPONENT THEREOF WHICH, IN THE OPINION OF THE COMPANY, HAS BEEN SUBJECTED TO NEGLIGENT HANDLING, MISUSE, ALTERATION, AN ACCIDENT, OR IF REPAIRS HAVE BEEN MADE WITH PARTS OTHER THAN THOSE OBTAINABLE THROUGH TECHNAUTICS.

PARTS OF COMPONENTS BEING CLAIMED FOR WARRANTY MUST NOT BE DISASSEMBLED OR ANY ATTEMPT MADE TO REPAIR THEM UNLESS APPROVAL IS GIVEN BY TECHNAUTICS. BREAKAGE OR DAMAGE RESULTING FROM INSTALLATION OR OPERATION NOT IN ACCORDANCE WITH TECHNAUTICS' PUBLISHED INSTALLATION AND OPERATING INSTRUCTION ARE NOT COVERED BY THE WARRANTY.

TECHNAUTICS DOES NOT WARRANT EQUIPMENT AND ACCESSORIES NOT OF OUR MANUFACTURE, WHICH ARE WARRANTED BY THEIR RESPECTIVE MANUFACTURERS, WHICH ARE EXTENDED TO THE PURCHASER THROUGH TECHNAUTICS.

ANY TECHNAUTICS PART OR COMPONENT COVERED BY THIS WARRANTY THAT IN OUR JUDGEMENT SHALL SHOW EVIDENCE OF A VALID DEFECT SHALL BE RETURNED TO TECHNAUTICS, FREIGHT CHARGES PREPAID.

IN NO EVENT SHALL THE COMPANY BE LIABLE FOR CONTINGENT OR CONSEQUENTIAL DAMAGES. THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES AND IS LIMITED TO THE REPLACEMENT OF PARTS RETURNED TO THE FACTORY AND DETERMINED DEFECTIVE ON INSPECTION. FEES INCURRED BY UNAUTHORIZED REPAIRS WILL NOT BE PAID/REIMBURSED.

## **WARNING**

### **DO NOT ADJUST THE EXPANSION VALVE**

*The expansion valve is factory set to the correct setting.  
If it is re-adjusted the warranty will be void, but more  
importantly you could screw up the system!*

## Spare and Replacement Parts and Pricing

ITEM	PRICE **
<b><u>Recharge Kit</u></b> Includes charging hose with valve and low-pressure gauge and 2-12oz cans of R-134a refrigerant	\$75
<b><u>Recharge hose</u></b> A R-134a recharge hose with valve and low-pressure gauge	\$45
<b><u>Replacement manual thermostat</u></b> CoolBlue refrigerator OR freezer thermostat	\$65
<b><u>12v Remote Electronic temperature display</u></b> CoolBlue refrigerator OR freezer thermostat	\$49
<b><u>Electronic Control module</u></b> The CoolBlue electronic control module powers and controls the compressor With compressor speed control and Error indicator LED Light	\$315

Technical support on your CoolBlue system is available 7 days a week via Skype, Email and Phone. In the event that you have any questions in the operation of your refrigeration system, please contact Technautics and we will be more than happy to answer your questions.

**Skype: CruiseROwater**  
**Email: [Info@TechnauticsInc.com](mailto:Info@TechnauticsInc.com)**  
**7 Day a Week Phone or Text: 619-609-3432**

**\*\*Prices Are Subject to Change Without Notice\*\***

